

CONGRATULATIONS YOU HAVE JUST BOUGHT THE COOPERSONIC DIRTBOX.....

This is a classic sounding overdrive / distortion that is probably best described as lying somewhere between the legendary coloursound overdrive and the lovetone big cheese....like all our pedals, this one goes a bit further than most and with the dirt control all the way up you'll get some pretty intense fuzz!

The Knobs:

1. Top left is the knob called 'DIRT' this will add more or less distortion or drive to your sound.
2. Top right is the 'LEVEL' knob, this is an overall volume control for the pedal.
3. The knob below and in the middle we have called 'BITE'. This is a tone pot with a difference, experiment and adjust to your liking.

The unit holds a regular 9 volt battery. Undo the 4 screws to insert a new battery and remember to remove the battery when the pedal is not being used for long periods. The battery is drawing power as soon as the input jack is inserted.

Alternatively, you can use a boss type 9 volt regulated adapter with 2.1mm plug, centre negative , approx 15mA.

www.coopersonic.com
info@coopersonic.com